


How to use your Space Heater

Rinnai



**Energysaver
RHFE-308FTR**

CONTENTS

Guarantee
Layout of appliance
Features
Safety Points
Operation
Adjusting Temperature
Economy Mode
Child-Lock
Humidifier
Clock
ON/OFF Timers
Override
Remote Control

**Remote Control
Included**

DUAL TIMER
Set and forget

RINNAI GUARANTEE OF QUALITY

As the purchaser of this high quality model RHFE-308FTR Rinnai product you are provided with the following guarantee:

	Free Labour	Free Parts
Heat Exchanger	1 Year	10 Years pro rata *
Fan	1 Year	2 Years
All other parts	1 Year	1 Year

*Full Heat Exchanger replacement (parts only) in the first year, thereafter reducing at 10% per year.

The benefits conferred by this guarantee are in addition to all other rights and remedies in respect of the product which you have under the Trade Practices Act and other State and Territory Laws. This guarantee does not cover cleaning and normal wear and tear, calls of this nature may be chargeable. Please check the fault finding charts on pages 18, 19, and 20, before asking for a service call. You may be able to overcome the problem without a service call, or the heater may be operating normally. Service calls to a heater which is operating normally may be chargeable, even when the heater is under guarantee.

The Installer is responsible for your heater's correct installation. There is no requirement to post the following information back to Rinnai. However we advise that you keep it in a safe place as your record.

Date of purchase:

Date of installation:

Retailers name:

Installers name:

Address:

Address:

Telephone:

Telephone:

Licence number:

IMPORTANT

This appliance shall be installed in accordance with:

Manufacturer's Installation Instructions

Local Gas Fitting Regulations

Municipal Building Codes

A.G.A. Installation Code for Gas Burning Equipment

Any other relevant Statutory regulation

This appliance must only be installed, serviced and removed by an Authorised Person

This appliance must be installed correctly by an Authorised Person. The installation of gas, and electricity must conform to local regulations.

The installation must also conform with the instructions supplied by Rinnai. Your Energysaver has been approved by the Australian Gas Association.

A.G.A. Approval Number: 5209

Please keep this instruction booklet in a safe place for future reference.

All dimensions referred to in these instructions are in millimetres, unless otherwise specified.

GETTING TO KNOW YOUR NEW RHFE-308FTR

LOUVRE

Warm air discharge duct.

HUMIDIFIER TRAY

Built into the warm air discharge duct. Humidifies the warm air flow.

BOTTOM TRIM

Pulls off to allow filling of humidifier tray.

REMOTE CONTROL BRACKET

CONTROL PANEL

Concealed panel with clock, room and pre-set temperature selection. Time, temperature and appliance error codes are shown here.

ON/OFF SWITCH

AIR INLET TUBE

Carries air for combustion.

GAS CONNECTION

ROOM TEMPERATURE SENSOR

ELECTRICAL CORD

AIR FILTER

Helps to protect the interior of the appliance and fan from dust particles.

EXHAUST OUTLET

Exhausts flue products to the outside of the building.

FLUE SYSTEM



The Australian Gas Association
Proudly a member of the AGA
All of our gas products are AGA tested and approved




Quality Endorsed Company

ISO 9002 Lic 4983
Standards Australia

Distributed and Serviced in Australia under a Quality System certified as complying with ISO 9002 by Standards Australia Quality Assurance Services.

REMOTE CONTROL


TO REPLACE BATTERY
Simply open the back of the remote control and replace Lithium battery.
TYPE: CR 2032



BATTERY
Power source for operating remote control.

REVERSE

ON BUTTON
Operates the heater manually.



OFF BUTTON
Stops heater manually.

TEMPERATURE ADJUSTMENT
Increases or decreases the temperature setting.

FRONT

■ NOTE


- Some fluorescent lights may interfere with the transmission of remote control signals, in this case changing the position from which you are operating the remote control may help.
- Avoid leaving the remote control in direct sunlight and do not place the remote close to the louvres of the heater.
- Avoid getting the remote control wet, or dropping it.
- The remote control works within 5 metres and an angle of 40° to the receiver on the heater.
- Only use the battery type specified. (CR2032).
- Remove battery if control is not going to be used for a long period. This will help to avoid damage from leaking batteries.



FEATURES

FORCED FLUE SYSTEM

Air for combustion is taken from outside the room and the flue products are exhausted outside, keeping the room air clean.



PUSH BUTTON IGNITION


Only one touch of the ON/OFF switch is required to operate the heater.



(See page 9)

WARM AIR DISCHARGE

Warm air flows from the bottom of the appliance through the louvres, assisting in even heat distribution. An integral humidifier tray is built into the warm air discharge duct.




PRE-HEAT

The function will automatically operate the appliance within one hour prior to the programmed time of the Timer. This is designed to heat a room to the pre-set temperature by the programmed time.

(See page 16)

DUAL ON/OFF TIMER


The Dual Timer allows you to programme the appliance to come on for two separate periods each day, usually one period in the morning, and one period in the evening. The built in Intelligent Mode brings the room temperature to the temperature you have selected, by the time programmed into the Timer.



The Dual Timer feature means that you can "Set and Forget" your heater. It will turn itself ON and OFF at times you have programmed until you cancel the Timer program.


FILTER INDICATOR

When the fan filter becomes covered with dust and the temperature inside the appliance rises, the filter indicator will flash. The filter should be vacuumed at regular intervals to avoid unnecessary strain on the appliance.



AUTO COMFORT


Ensures that the flow of warm air from the louvres is maintained at a comfortable volume during the warm-up period by a 8 step modulating convection fan, in conjunction with the thermostat, reducing cool draughts.



(See page 11)


REMOTE CONTROL

For the convenience of turning the heater ON or OFF, as well as adjusting the temperature up or down while at a short distance from the heater.



CHILD LOCK


When the Child lock is activated all controls other than the OFF switch will be locked. Deactivating the lock releases the controls. If the lock is activated when the appliance is off, all functions will be locked.



(See page 11)

ECONOMY MODE

This is an energy saving feature designed to reduce the room temperature to 1°C less than the pre-set temperature over a period of 30 minutes, and an additional 1°C after another 30 minutes.




MEMORY


The micro-computer records selected pre-set temperatures, the times programmed into the Timers as well as operating the Economy and Intelligent modes, to maintain comfort levels.

SAFETY POINTS

Do not restrict the warm air discharge by placing articles in front of the heater.




This appliance must not be used for any purpose other than heating.



7


Do not spray aerosols whilst the heater is operating. Most aerosols contain butane gas, and can be a fire hazard if used near this heater when it is in use.



Flue guard is recommended where children may be able to touch the flue terminal.



Do not allow curtains or other flammable or combustible materials to come into contact with the heater.




Combustible materials must not be placed where the heater could ignite them.

Do not allow anyone to sit on or lean against the appliance.




SAFETY POINTS


Keep flammable materials, trees, shrubs, etc, away from the flue terminal.



Do not allow anyone to post articles through the louvres.




Filter should be cleaned at regular intervals. See Page 12.




Clean with vacuum cleaner, weekly.


Young children should be supervised at all times. Hand or body contact with the louvres should be avoided.



Do not place articles containing liquids on top of the heater. Liquids spilt on the controls may cause extensive damage.




Do not allow young children or the infirm to sleep directly in front of the heater.



OPERATING YOUR NEW RHFE-308FTR


■ TO OPEN THE CONTROL PANEL

Lift lightly in the centre of the lid where there is a catch. The control panel lid will then drop backward to an angle.



■ TURNING ON


Press the ON/OFF button to operate the heater. The ON indicator will glow green. After approximately 20 seconds the spark generator will be heard before the burner ignites and the ON indicator glows red, indicating that the burner is alight. Warm air can be felt coming from the louvres 15 seconds later.



If the heater does not ignite on initial use, this may be due to air remaining in the gas supply line. The spark generator will only continue for 15 seconds. After this it will be necessary to press the ON/OFF button OFF, then ON again.

■ TURNING OFF

Simply press the ON/OFF button to switch off the heater. The ON indicator will go out. The convection fan will continue to operate for several minutes after the burner has gone out in order to cool the appliance. **Do not unplug the appliance while the convection fan is running.**



DO NOT turn heater off by unplugging at the power point.
The convection fan will continue to run until the appliance cools.

■ ROOM TEMPERATURE ADJUSTMENT


The room temperature and pre-set temperatures can only be displayed and adjusted when the heater is running.

1

Press the "▲" button to increase the temperature setting or "▼" button to decrease the temperature setting.

The Temperatures can be preset to:

- a) [L] low (about 10°C)
- b) [16°C] to [26°C] in 1° C steps
- c) [H] (continuously high)




If the heater does not ignite then the pre-set temperature may not be set to a setting which is higher than the room temperature. The ON indicator will change colour from red to green when the heater reaches the pre-set temperature and stops running.

■ ECONOMY MODE

The Economy mode may only be operated when the heater is turned on, but remains in the system memory once set until deactivated. Select the Economy mode before selecting timer operation.


1

Press the Economy button to start the Economy function. The Economy indicator will glow.




2

Press the Economy button once more to switch off the function.



After the room is heated initially the air temperature may be dropped to a lower level without affecting comfort. 30 mins after the selected room temperature (set with the thermostat) is reached, the Economy mode, if set, reduces the temperature by 1°C. After another 30 mins it reduces the temperature by a further 1°C, this is an energy saving feature. The Economy mode does not operate if the heater is under capacity for the room size.




■ CHILD LOCK

The Child lock will help to prevent accidental operation as well as small children from altering the controls.


1

To operate the Child lock simply press the Child Lock button. The function is activated immediately and the Child lock indicator will glow.



2

To deactivate the Child lock simply press the Child Lock button for 2 seconds and the Child lock indicator will go out. The lock can be deactivated at any time in this way.



During normal operation the Child lock may be activated and all controls other than the OFF switch will be locked. Deactivating the lock releases the controls. If the lock is activated whilst the heater is turned OFF, then all functions will be locked. If the heater is turned OFF whilst the Child lock is activated, it cannot be turned ON again until the lock is deactivated.

■ AUTO COMFORT

11 A room temperature sensor located at the rear of the appliance is continuously monitoring the temperature of the room. The main purpose of Auto Comfort is to improve control over the flow of warm air being discharged through the louvres when the heater is first operated. The means by which this control is achieved is an 7 speed modulating convection fan and the temperature sensor, in conjunction with a micro-computer.

In order to achieve comfortable heating, it is preferable to avoid cold draughts from the appliance. In the case of a conventional fan heater, the convection fan operates normally from the time of ignition and a cool draught may accompany the flow of air from the appliance.

To overcome this situation, fuzzy logic controls the speed of the convection fan after taking into consideration the room temperature at the time of ignition. For example: the room temperature is low, then the fan rotates at low speed. As the room temperature rises the speed of the convection fan gradually increases.

In this way it is possible to ensure a comfortable flow of warmed air, as well as decreasing the sensation of cold draughts immediately after ignition.

The convection fan speed increases proportionally as the room gradually heats up. This improves the warm air distribution, assisting in a reduction of warm air stratification throughout the room, and resulting in more effective heating conditions.


The micro computer continuously monitors the room temperature and adjusts the convection fan speed according to the conditions at the time.

■ FAN FILTER

To protect the room air fan from dust particles or lint, a filter is situated at the rear of the appliance. When this filter becomes blocked, the filter indicator will flash to indicate that it should be cleaned. Clean the filter weekly during the heating season to avoid unnecessary strain on the appliance.

Do not remove filter when appliance is operating. When the filter requires cleaning, clean filter before using the appliance, or whilst the appliance is not operating.

If you do not clean the filter at regular intervals and the filter indicator is allowed to remain flashing, then the appliance will stop and [14] will flash on the Digital Display signifying that the inbuilt safety device has functioned. You must clean the filter before operating the heater again.




■ HUMIDIFIER TRAY

So that you can humidify the air, your Rinnai RHFE-308FTR is fitted with an enamelled tray at the bottom of the heater. If you choose to make use of the humidifier tray, it will need filling about once a day during the heating season. **Do not fill the humidifier tray while the heater is running.**

1 To fill the humidifier tray:

Remove the bottom trim panel, below the louvres, by pulling on both sides. Simply pull the tray forward to allow it to be filled with water. The warm air will be humidified as it passes over the water in the tray. Refit the bottom trim panel after filling the tray. The RHFE-308FTR is a very high efficiency appliance, during operation a small amount of condensation is produced in the flue system, this drains into the enamelled humidifier tray.




The humidifier has the benefit (when filled with water) of raising the humidity in the air. With increased humidity, the heater can actually be run at a lower temperature while still maintaining the same level of comfort.

■ VERTICAL LOUVRE ADJUSTMENT

The warm air flow direction may be altered by inserting a screwdriver or similar tool and gently bending the vertical louvre(s) either to the left or the right.


Note: These louvres are not designed to be adjusted more than 6 times.



SETTING THE CLOCK

When the appliance is first plugged in and then turned on, the Digital Display will show --:--.

As an example, let's set the clock to 10:35 am.




OPEN THE CONTROL PANEL-SEE PAGE 9.

1


When the appliance is first plugged in or after a power failure, the Digital Display will show --:--.

Press the Set Times button once, the Clock Indicator will flash.




2

Press and hold the "▲" button; the minutes will begin to change first, then the time will change by whole hours. Release the button when AM 10:00 shows on the Digital Display. Confirm that you have selected AM, a small indicator on the left hand side of the Digital Display indicates the AM setting.




Press and hold the "▲" button again, release the button when AM 10:35 shows. If you go past AM 10:35, then the "▼" button can be used to change the time settings in reverse.



3

Press the Timer Set button five times to lock in and complete setting the time. The Clock and Timer indicators will go out. A small indicator on the Digital Display will flash to show that the clock is operating.




PROGRAMMING THE ON/OFF TIMER(S)

Before programming the Timers you must ensure that the clock has been set to the correct time. See page 13.

As an example let's programme Timer 1 to heat the room by 7:10 AM and finish at 9:00 AM.


1

Press the Set Times button twice. The Digital Display will show AM 6:00. Timer 1 indicator will flash.




2

Press the "▲" button until AM 7:00 appears, release the button, then press it again until AM 7:10 appears. (Press the "▼" button if you go past AM 7:10.)




3

Press the Set Times button again, the Timer 1 OFF indicator will flash. Press the "▲" button until AM 9:00 appears.



4

Press the Set Times button three times to lock in the programmed time. The Digital Display will show the current time. A small indicator on the Digital Display will flash to show that the Display has returned to the clock.



TURN TO NEXT PAGE TO OPERATE THE TIMERS.

TIMER 2 is programmed in the same way, remember to ensure that the Timer 2 indicator is flashing when you programme in the desired setting.

The Timers can be programmed to operate for any two periods in any 24 hours. Turn to next page to operate the dual timer.

The programmed time must be selected and locked-in within one minute of the On Timer indicators flashing otherwise the programmed times will not be retained in the system memory.


OPERATING THE TIMER(S)

Before operating the Timer(s), the clock time must be correct, and a starting time and finishing time for the Timer(s) must be programmed. See pages 13 and 14. The two Timers operate in the same way. This heater does not commence operation at the programmed starting time. It will attempt to heat a room by the programmed starting time. See Pre-heat page 16, for further explanation.

1


To select the Timer(s) to commence heating:

Check the time shown on the Digital Display is correct. See page 13. Check the ON and OFF times, for both Timers if necessary, see page 14.



2


Press the ON-OFF button to operate the heater. The On indicator will glow green and the heater will begin to operate. Select the desired temperature setting.



3

Press the Timer 1 and/or Timer 2 button(s).

The Timer indicator(s) will glow and the heater will remain on standby until one hour prior to the time programmed into the selected Timer(s) is reached. When this time is reached, the Timer indicator will flash and the heater will operate. The ON indicator glows red when the heater commences operation.



SET AND FORGET OPERATION

Your heater can be operated to alternate between Timers automatically during cold weather by selecting Timer 1 and Timer 2 together. Both Timer indicators will glow. The appliance will remain on standby at intervals between the programmed finishing and starting times of each Timer. While the heater is operating during programmed intervals the Timer indicator will flash.

If there is a power failure, the system memory will retain the Timer programs, and the clock will stop at the time the power goes off. The clock will start again when the power comes back on, but the time will be slow by the duration of the power failure. To set the clock to the correct time after the power has come back on, simply follow the instructions on page 13.

PRE-HEAT

1


This function operates automatically in conjunction with either of the Timers. When a Timer is selected, the heater may operate anywhere within an hour prior to the programmed starting time of the Timer.

The Pre-heat function will heat a room to the pre-set temperature by the programmed On Time.

This function is called Pre-heat due to the way it operates. The room temperature is sensed one hour before reaching the programmed time of either Timer.

The temperature differential at the time of sensing the room temperature, combined with the data from the previous operation governs exactly how long before the programmed On time the micro-computer will operate the heater and ignite the burner.


The following chart may help to improve understanding of the Pre-heat function.



This function is intended to be used to manually override the current operation of the heater. For example; if the heater is in standby mode (i.e. between finishing time and starting time of a Timer), and the Override button is selected, then the heater will begin to operate, and heat the room.


1

To operate the Override simply press the Override button. The Override indicator will flash.



2


To manually deactivate the Override simply press the Override button again. The Override indicator will go out, and the heater will return to standby mode.




The heater will continue to operate on Override until the Override button is pressed again, or one of the Timers takes over the operation of the appliance. This means that the Override mode will automatically drop out if a programmed Starting time is reached. The appliance will then return to operating at times programmed into the Timer(s).

Remote Control will not turn heater ON if Timer(s) have been selected.

To manually operate when Timer(s) are not selected, simply press the ON or OFF button.



To alter the temperature at any time while the heater is operating, simply press the "▲" or "▼" buttons.



If the Timer(s) have been selected, and the heater is in standby mode, and the OFF button on the Remote Control is pressed, the Timer(s) will be deactivated.

CARING FOR YOUR NEW RHFE-308FTR

This appliance is controlled by a micro computer. If there is something wrong with the appliance then it will stop, as it is protected by the following safety devices.


Ignition Safety Device
Burner Safety Device
Overheat Safety Device

Power Failure Safety Device
Power Surge Safety Device
Fan Delay Safety Device

Your RHFE-308FTR requires very little maintenance, simply clean the rear fan filter once a week and wipe the outer case and louvre section with a damp cloth.

DO NOT USE SOLVENTS.

Solvents may melt or distort plastic parts.



Problem Cause	No ON indicator	Burner doesn't ignite	Unusual combustion	Combustion stops during operation	Smell of gas	Noisy Ignition	Takes too long to warm the room	Remote control doesn't work	Remedy
Not Plugged In	●	●							Plug In
Power Cut	●	●		●					Re-ignite manually after power is restored
(Initial Installation) Air in gas pipe		●							Purge air (Installer)
Gas Filter Blocked		●	●				●		Service Call
Miss Ignition	●	●							Service Call
Flue terminal obstructed			●	●		●			Clear obstruction
Flue manifold not connected						●			Service Call
Louvre obstructed				●			●		Clear obstruction
Air filter blocked				●			●		Clean filter (weekly)
Gas Escape					●				Service Call
On Timer is set		●							Cancel On Timer
Child Lock set		●							Cancel Child lock
Gas turned off at meter	●	●							Turn gas on
Battery flat (remote control)								●	Replace battery

PRE-SERVICE CHECK

Before asking for a service call please check the following points.
These points are part of the normal operation of the unit.

■ At Ignition:

Heater does not operate.

→

Is the heater plugged in?
Have the fuses or breaker blown at the switch board?
Is there a power failure?
Is the air filter blocked?
Is anything blocking the outlet for the hot air?
Is the flue blocked?
Are Timers set? Clear Timers and operate again.

Warm air does not flow when the burner lights.

→

The fan is started automatically after a short delay.
This is to allow the heat exchanger to warm up,
helping to avoid cold draughts.

Smoke or strange smells are produced on the first trial light up after installation.

→

This is caused by grease or oil and dust on the heat exchanger
and will stop after a short time.

Sharp clicking noises at ignition, or when the unit cuts down on the thermostat, or goes out.

→

This is simply expansion noise from the heat exchanger.

■ During combustion:

Clunking noise when the thermostat operates.

→

This is the sound of the solenoid gas valves opening and closing.

Unit is not heating room.

→

Is the air filter blocked?
Is the set temperature high enough?
Is the warm air outlet blocked by anything?
Are the doors and windows of the room closed?

Air filter is blocked or the louvres are blocked or obstructed.

→

Allow heater to cool, clean air filter, operate again.

Heater will not re-ignite after overheating.

→

Even after unit has cooled down the heater does not ignite again. Repair is necessary.
Contact your local agent or Rinnai for a Service call.

■ When the unit is turned off:

Convection fan continues to run after turning OFF.

→

This is to remove the residual heat from the heat exchanger, the fan will stop when the heater cools down.

■ Other Points:

Steam is discharged from the flue terminal.

→

High efficiency appliances tend to discharge water vapour on cold days, this is normal.

Unit cuts off without apparent reason.

→

Check whether filters are blocked, dirty filters will cause the heater to overheat.

Power Failure.

→

Switch OFF, then ON again when power is restored to re-set controls.

ERROR MESSAGES

The Energysaver RHFE-308FTR has the ability to check its own operation continuously. If a fault occurs, an Error Message will flash on the Digital Display of the control panel. This assists with diagnosing the fault, and may enable you to overcome a problem without a service call. Please quote the code displayed when enquiring about service.

CODE DISPLAYED	FAULT	REMEDY
11	Ignition failure	Check gas is turned ON. Service call if repeated.
12	Flame failure	Check gas is turned ON. Service call if repeated.
14	Overheat	Clean filter Service call if repeated.
16	Room overheat	Lower room temperature to less than 40°C.
31	Room Temperature Sensor faulty	Service call
32		
33	Overheat temperature Sensor faulty	Service call
34		
53	Sparker failure	Service call
61	Combustion fan failure	Service call
70	Faulty ON/OFF switch	Service call
71	Faulty solenoids	Service call
72	Faultly Flame Rod	Service call
73	Communication Error	Turn heater OFF, then ON again.
--:--	Power failure	Turn heater OFF, then ON again.

In all cases, you may be able to clear the Error message simply by turning the heater OFF, then ON again. If the Error Message still remains or returns on the next operation, contact Rinnai or your nearest service agent and arrange for a service call.

INSTALLATION INSTRUCTIONS

SPECIFICATION

Input: 13 MJ/h

Burner: Stainless Bunsen Type

Ignition: Continuous Spark













Gas Inlet: R $\frac{1}{2}$ 15 BSP Connection

Flue: Forced Flue (Components are supplied with appliance).

Gas Control: Rinnai Electronic Modulating Controls.

Electrical Supply: 240V, 50 Hz. This appliance is fitted with a supply lead and 3 pin plug.
Replace only with Rinnai part number 3010.

- Remove parts from carton and check that all parts shown below are included in the installation kit.

Flue Manifold.....1			Spare rubber seal1 (‘A’ Flue units only)		
			 (For weatherboard installations)		
Back Spacer Set		1	Flue Locking Clamp		1
			Insulation Clip		1
			Hose Clip		2
Wall Bracket		2	Plastic tie for air inlet		1
Customers operating information and Installation Instructions		1			
(M4)	 For Back Spacer Set	8	(M4)	 Flue Securing Screws	3
(M4)	 For Air Intake Clip	2	(M4.8×32) Wood Screws	 Wall Bracket Screws	2

Check the unit supplied is correct for the gas type in your area.

Refer to local gas authority for confirmation of gas type if in doubt.

Refer to data plate located inside the front panel.

Check for damage, if the unit is damaged contact your supplier or Rinnai.

Do not install a damaged unit before checking with your supplier.

Refer to an approved pipe sizing chart if in doubt about size of gas line.

LOCATION



When positioning the heater the main points governing the location are:

1. Flueing
2. Warm air distribution

This heater must not be installed where curtains or other combustible materials could come into contact with it.


In some cases curtains may need restraining.

See diagram for other recommended clearances.




Flue fittings must be kept clear of flammable materials.


This heater is not designed to be built in.



The flue is not designed to be positioned under floors, or below the level of the heater.



The flue terminal should be positioned away from flammable materials.




LOCATION

Do not flue into natural draught flues or fireplaces, this unit can only be used with one of the six types of Rinnai flue kits.

Do not flue unit into other rooms.

Flue terminal must be outside.



Flue may be positioned directly under opening windows, with a minimum clearance of 150 mm.


FLUE SIZES:

6l Flue lengths are available.

- AA flue suits wall 75 - 115 mm
- A flue suits wall 115 - 240 mm
- B flue suits wall 240 - 400 mm
- C flue suits wall 400 - 600 mm
- D flue suits wall 600 - 800 mm
- E flue suits wall 800 - 1000 mm

Co-ax flue also available.


SNOW AREAS




In areas subject to heavy snowfall, keep snow clear of flue terminal at all times.

STANDARD INSTALLATION OF FLUE MANIFOLD.

Diagram below shows minimum clearances and distances from obstructions. Also check local regulations.




Side Clearances



FIT BACK COVERS (SIDES ONLY)

Fit back covers (sides only) as shown below.




GAS CONNECTION


Fit suitable copper flare elbow to appliance inlet.

LOCATION

Do not install the heater in an unusually dusty area.



- Use a flue guard if the terminal is easily accessible to children.
- Check local regulations.
- Guards are available as an optional extra.




- Floor must be level.
- Do not use electrical extension cords to connect the unit to a power supply.
- Keep the power cord away from the flue.

FLUE MANIFOLD POSITION

Important

The centre of the hole for the flue manifold must only be drilled in the position indicated on the diagram below.



Before drilling the flue hole, check for water and gas pipes as well as electrical cables.

For weatherboard walls drill through centre of the weatherboard from the outside, then drill from inside through the plaster board.

WALL MOUNTING BRACKETS


- Place top back spacer.
- Mark the position of the top edge of the top spacer on the wall.
- Move the heater away from the wall.
- Mark the centre lines 30 mm down from the top edge mark, and 40 mm in from the left and right hand sides of the top spacer.
- Attach wall brackets at the marked position. Remove right hand back spacer.

SLEEVE AND MANIFOLD INSTALLATION

METHOD FOR STANDARD WALLS


1. Dis-assemble Manifold from Sleeve.

The flue consists of 3 parts, sleeve, inside connectors and tube, outside terminal; (dis-assemble by pulling hard on outside terminal and inner connections, then pull sleeve off outer terminal).




2. Adjustment of Sleeve Length.

Measure wall thickness through previously drilled 80 mm hole. End of sleeve should protrude 5-10 mm from outside wall. Adjust sleeve length to wall thickness plus 5 -10 mm. (Sleeve is threaded for adjustment).



3.) For A and AA flues only

Depending on flue set and wall thickness extension piece "C" may need to be removed. Cut plastic, remove extension, then follow instruction 2. This applies to "A" and "AA" flues only. There is no extension on other flues, they can be fully adjusted by turning the threaded section.




4. Fixing Sleeve.

Fix to the wall, using the 3 screws provided.

NOTE:

The flange is marked "TOP", sleeve must be fitted with this mark UP. Check sleeve protrudes 5-10 mm on the outside.



Don't remove green plastic covering from sleeve.

SLEEVE AND MANIFOLD INSTALLATION


METHOD FOR STANDARD WALLS

5. Check rubber seal is in place on terminal.

* For weather board walls, add spare rubber seal provided to compensate for weatherboard angle.


Terminal seal

(Add "weather board" seal here)




6. Installation of Terminal

From outside, insert terminal into sleeve with the "A" mark at the top. Left hand side fixing tie is marked "LEFT" (from inside).




7. Attaching Ties


Pull hard on left and right hand side ties, clip ties over lugs inside sleeve. You should be able to pull ties 2 or 3 slots past the starting point. Cut the ties, leaving about 20 mm past the lugs. Bend ties so they are parallel with the wall.



8. Insert Inner Connection Assembly. Push assembly into the terminal tube, make sure "TOP" mark is uppermost. Fix with 3 screws provided.




9. Manifold can still be turned after attaching.




FITTING UNIT

AIR INLET HOSE



Attach the Air Inlet Hose to the flue manifold on either inlet position a or b. The unused inlet is plugged with the rubber cap supplied on the manifold.

2.




Fit the locking clamp over the connection between the flue elbow and the manifold. Engage the hook and rotate it until it snaps against the body of the clamp.

EXHAUST PIPE & LOCKING CLAMP


The following components can be fitted by reaching down the rear of the appliance as it is positioned against the wall.

1.




Connect the flue elbow to the manifold by moving the appliance into position.

3.



4.



Slide the insulation sleeve up to the flue manifold and slip the securing clip over the sleeve as shown

TESTING



Purge air and swarf from gas line. Connect gas. Connection can easily be reached from the right hand side rear of the appliance.



Remove bottom trim (pulls off). Remove louvres and front panel. (7 screws)

PRESSURE CHECKING PROCEDURE:

Caution-240 V inside appliance.

1. Check that SW6 (Dip switches) are correct for the gas type for which the appliance is to be used. (Refer to diagram opposite).
2. There are two test points, one on the heat exchanger, one on the gas manifold. Connect a pressure gauge between both test points. (Connect one side of the gauge to one point, the other side of the gauge to the other). If you are using an electronic manometer, connect the \ominus side to the heat exchanger test point.
3. Press the ON/OFF button to operate the appliance.
4. With the appliance operating, press SW5 once.
5. Press SW4 to operate the appliance on forced low.
6. Check the pressure against the low pressure shown on the data plate. (Right hand side panel)
7. Press SW4 again.
8. Press SW3 to operate the appliance on forced high.
9. Check the pressure against the high pressure shown on the data plate.
10. Press SW3 again.
11. Press SW5 again to return the heater to normal operation.
12. Turn the heater OFF, remove the pressure gauge, and replace the test point screws.
13. Reassemble appliance, set the clock, (See page 13) and check appliance operation.


		SW6 DIP SWITCH
308FTR	NG	OFF ON OFF OFF  1 2 3 4
	LPG	ON OFF OFF OFF  1 2 3 4



THE REGULATOR HAS BEEN FACTORY PRE-SET. IF THE PRESSURE IS INCORRECT, CHECK THE SUPPLY PRESSURE FIRST, BEFORE MAKING ANY ADJUSTMENT TO THE APPLIANCE.


IF THE PRESSURE NEEDS RE-SETTING FOLLOW THE INSTRUCTIONS BELOW.

1. Follow checking procedure 1-6, reset the low pressure by using the "▲" or "▼" buttons on the control panel.
2. Press SW4 again to lock in the selected setting.
3. Follow checking procedure 8 and 9, reset the high pressure by using the "▲" or "▼" buttons on the control panel.
4. Press SW3 again to lock in the selected setting.
5. Press SW5 to return the heater to normal operation.
6. Turn the heater OFF, remove the pressure gauge, and replace the test point screws.
7. Reassemble appliance, set the clock (See page 13) and check appliance operation.




FITTING TOP SPACER + WALL CLIP

■ SECURE HEATER TO WALL




Replace top and right hand spacers, clipping the top spacer into the wall brackets at the same time as attaching it to the heater.

Secure top spacer with the screws provided. THE HEATER IS NOW SECURED TO THE WALL.



OPTIONAL FLOOR BRACKETS ARE AVAILABLE FOR COMMERCIAL INSTALLATIONS.

Tighten all screws, fit fan filter.



■ INSTRUCT CUSTOMER ON USE OF HEATER


When you are satisfied that the appliance is operating correctly, explain operation of heater to the customer.

Fault-Failure Procedure

If unable to get the heater to operate correctly, contact Rinnai directly or your Agent or Gas Utility.


BLOCK and WIRING DIAGRAM

WIRING DIAGRAM




MARK	PART NAME
MS	MAIN SWITCH
TH	THERMISTOR
TF	THERMAL FUSE
F	FUSE
CF	CONVECTION FAN
FCC	FAN CONTROL CIRCUIT
ER	ELECTRODE
POV	MODULATING SOLENOID VALVE
TR	TRANSFORMER
RC	REMOTE CONTROL
TB	TERMINAL BLOCK
OH.TH	OVER HEAT THERMISTOR
OHS1-2	OVER HEAT SWITCH 1-2
FM	FAN MOTOR
BL	COMBUSTION FAN MOTOR
SP	SPARKER
FR	FLAME ROO
SV1-7	MAIN SOLENOID VALVE 1-2
CPU	CENTRAL PROCESSING UNIT
RCR	REMOTE CONTROL RECEIVER

BLOCK DIAGRAM



CODE	COLOUR
pl	purple
y	yellow
w	white
gr/y	green/yellow
gy	grey
bl	blue
r	red
bk	black
or	orange
br	brown
gr	green

DIMENSIONS



SERVICE CONTACT POINTS

Rinnai Australia PTY. LTD. A.C.N. 005 138 769

Internet: <http://www.rinnai.com.au>

Head Office: 10-11 Walker Street, Braeside, Vic 3195.

E-mail: enquiry@rinnai.com.au

Tel: (03) 9271 6625. Fax: (03) 9271 6622.
 Sales: (03) 9271 6666. Fax: (03) 9271 6611.
 Service: (03) 9271 6699. Fax: (03) 9271 6688.
 Spare Parts: (03) 9271 6600. Fax: (03) 9271 6688.
 24 hr Hot Water Tel: (1800) 632 386.

N.S.W. Branch: 62 Elizabeth Street, Wetherill Park, NSW 2164.

Tel: (02) 9609 2111. Fax: (02) 9609 5260.
 Sales: (02) 9609 2888. Fax: (02) 9609 5260.
 Service: (02) 9609 2600. Fax: (02) 9729 0467.
 24 hr Hot Water Tel: (02) 9729 0468.

S.A. Branch: 140 Days Road, Ferryden Park, SA 5010.

Tel: (08) 8345 0292. Fax: (08) 8345 4760.
 24 hr Hot Water Tel: (018) 81 4379.

W.A. Branch: 18 Belgravia Street, Belmont, WA 6104.

Tel: (08) 9478 3355. Fax: (08) 9277 2531.
 24 hr Hot Water Tel: (08) 9324 4145.

QLD Branch: 1/6 Booran Drive, Logan Central, QLD 4114.

Tel: (07) 3209 4622. Fax: (07) 3209 4722.

A.C.T. Rinnai Southern (Bird & Stirling Agencies Pty. Ltd.)
 3 Lithgow Street, Fyshwick, ACT 2609.

Tel: (02) 6280 4833. Fax: (02) 6280 6561.
 24 hr Hot Water Tel: (02) 9729 0468.

Tasmania: Contact Rinnai Melbourne Head Office:

Rinnai New Zealand LTD.

691 Mt Albert Road, Royal Oak, Auckland.

PO Box 24-068 Auckland Tel: 625 4285, 0800 RINNAI, Fax: 624 3018.