



RHF561FT3 Energysaver Space Heater

Service manual

Rinnai

Important

This information is being made available to qualified tradespeople such as licensed gasfitters and plumbers. It is not intended for use by non-qualified people or members of the public.

Gas appliances **MUST BE** serviced by an authorised person, being in New Zealand a licensed gasfitter, in accordance with the manufacturer's service instructions and all applicable local rules and regulations.

Installation, servicing and repair shall be carried out only by authorised personnel.

Warning

Improper installation, adjustment, alteration, service and maintenance can cause property damage, personal injury or loss of life.

For more information about buying, using, and servicing of Rinnai appliances call: 0800 RINNAI (0800 746 624).

Rinnai New Zealand Limited
105 Pavilion Drive, Mangere, Auckland
PO Box 53177, Auckland Airport, Auckland 2150

Phone: (09) 257-3800
Email: info@rinnai.co.nz
Web: rinnai.co.nz
youtube.com/rinnainz
facebook.com/rinnainz

Contents

Specification	4
Unit dimensions	5
Cutaway diagram.....	6
Schematic operation.....	7
Safety devices	8
Error codes	9
Fault finding	10
Operational flow chart.....	12
Diagnostic points	14
Wiring diagram	15
Block diagram.....	16
Time charts.....	17
Dismantling for service	20

Parts lists

The exploded diagrams and parts lists have not been published in this manual due to the frequency in which they change. Please refer to the Rinnai website (rinnai.co.nz) for the latest spares PDF's.

Specification



Description

Designed and made in Japan, Rinnai Energysavers are externally flued gas appliances designed to be installed against a wall. They are intended for installation in living spaces and open plan areas.

Colour - white with grey louvres.

Scope of use

Ideal for living rooms, bedrooms, and open plan areas as space heaters. Versatile power flue system makes for easy installation in almost any living space.


Energysavers must not be built in, for example into a bookcase or into walls.

Code - NG	RHF561FT3WN
Code - LPG	RHF561FT3WL
Efficiency¹	82.9%
Input¹	9-23 MJ/h
Output²	2.2-5.3 kW
Humidifier tray capacity	1.0 L
Noise level	34-42 dB(A)
Power consumption	Approx. 36 W (high), < 1 W on standby
Temperature range	16-26 °C
Gas connection	15 mm BSP male thread
Injectors NG	4 x Ø1.25 mm
Injectors ULPG	4 x Ø0.82 mm
Data plate position	Lower right hand side
Weight	23 kg
Features	Preheat, dual timers, manual control, electronic ignition, economy, fan filter, overheat safety device, and lock
Market release	NG model Oct 2023, LPG model Jul 2025


¹ Input, output, and efficiency will vary depending on gas type and flue length.

For gas pressures and gas type, refer to the data plate on the lower right hand side of the unit


Unit dimensions



Cutaway diagram



Schematic operation



Safety devices

Overheat switch

This device automatically shuts the gas supply off if the heater exceeds a predetermined temperature. This is normally caused by an obstruction in front of the louvres, or a blocked fan filter.

If the overheat switch operates, turn the unit 'OFF', remove the obstruction (clean filters) and allow the unit cool off for 10-15 minutes before re-operating.

Fusible links

The fusible link activates under conditions of severe overheating and shuts off the gas supply. A service call will be required to repair the appliance.

Flame failure device

If the flame goes out during operation this device shuts off gas to the burner. To reset, turn the unit 'OFF', then 'ON' again. If this happens repeatedly a service call is required.

Electrical fuse

The electrical circuits are protected by an electric fuse. When the fuse blows, the heater will not operate. The fuse must be replaced by an authorised person.

Power failure

In the event of a power failure or power cut, the gas valves will automatically close. This unit will NOT re-light after the power is re-instated. The time of day will need to be reset to the correct current time.

Blocked flue pressure module

In the event the flue is blocked the, unit will not start. If the flue becomes blocked while the unit is on, it will shut off automatically.

Error codes

Error code	Likely cause	Comments
00	Power failure	When power failure is sensed operation stops.
11	Ignition failure	Check gas supply, check sparker, and gas solenoids.
12	Flame failure	Check adequate gas supply, check flame rod, and check flueing.
14	Overheat	Check air filter, convection fan (clean if dusty). Check burner pressures—if 14 comes up before unit is on, check thermal fuse.
16	Room overheat	Lower room temperature to less than 40 °C. If the units detects 40 °C for over ten minutes, the unit will stop operating.
30	Overheat temp. sensor faulty	
31-32	Room temp. sensor faulty	Check resistance, refer diagnostics page for values.
33-34	Overheat temp. sensor faulty	Check resistance, refer diagnostics page for values.
40	Sensor sensing tube failure	Confirm commissioning has been completed in accordance with instructions. Ensure tht the pressure check tube is not blocked, pinched or crushed.
49	Pressure module not activated	Check voltage to pressure module pressure hoses are connected correctly and for flue obstructions.
53	Erratic spark	Check spark gap, spark lead, and spark electrode insulation cap.
61	Combustion fan failure	Replace combustion fan
62	Convection fan failure	Replace convection fan (rev counter faulty)
70	Faulty on/off switch	Remove Control PCB and check and check for anything causing tracking across the tracks, if ok, replace board.
71	Faulty solenoid circuit detected	Check wire connections between main PCB and solenoids.
72	Faulty flame rod	Check for cracked ceramic and lead.
73	Communication error	Make sure all of the connectors on main PCB are in place , Turn power off and on if still faulty change main PCB.
81	Faulty solenoids	
99	Pressure module not activated	Check for flue obstruction. Check gas type and flue length settings are set correctly.

Fault finding



HAZARDOUS VOLTAGE
Risk of electrical shock



Disconnect all
sources of supply
prior to servicing





- All electrical supply **MUST BE** disconnected before servicing or repairing the heater.
- 230 V potential exposure. Isolate appliance and reconfirm with a neon screwdriver or multimeter.

	No power on / combustion indicator	Burner doesn't ignite	Unusual combustion	Combustion stops during operation	Smell of gas	Noisy ignition	
Not plugged in	●	●					Plug in power cord and press the control panel on/off button.
Power cut	●	●		●			Re-ignite manually after power is restored.
Initial installation, air in gas pipe		●					Purge air (installer).
Gas filter blocked		●	●				
Mis-ignition	●	●					
Flue terminal obstructed			●	●		●	Clear obstruction.
Flue manifold not connected					●	●	
Louvre obstructed				●			Clear obstruction.
Air filter blocked				●			Clean and advise customer to regularly clean.
Gas escape					●		
On timer is set		●					Cancel on timer or press the override button.
Gas turned off at meter		●					Turn gas on
Function / child lock set		●					Cancel function / child lock
Flue outlet blocked / obstructed		●		●			Clear obstruction

Symptom	Explanation
At ignition	
Warm air does not start when the burner lights	The fan is started automatically after a short delay. This is to allow the heat exchanger to warm up, helping to avoid cold draughts.
Smoke or strange smells are produced on the first trial light up after installation.	This is caused by grease or oil from the manufacturing process on the heat exchanger and dust, and will stop after a short time.
Sharp clicking noises at ignition, or when the unit cuts down on the thermostat, or goes out.	Expansion noise from the metal heat exchanger, this is normal.
During combustion	
Clunking noise when the thermostat operates.	This is the sound of the solenoid gas valves opening and closing.
When the unit is turned off	
Convection fan continues to run after turning 'OFF'	This is to remove the residual heat from the heat exchanger. The fan will stop when the unit cools down.
Other	
Steam is discharged from the flue terminal.	High efficiency appliances tend to discharge water vapour on cold days. This is normal.
Heater does not start even when 'ON' button is pushed and thermostat is on HIGH.	Check timer. Timer must be in the "OFF" position for manual operation. Room temperature is hotter than 'High' setting.
Timers	
Timers do not operate at set time.	Timers may either be inactivated or incorrectly programmed. Repeat programming.
Timer operates for 30 seconds then cuts out.	Room temperature may be higher than set temperature. Adjust temperature upwards if desired.

12 | ES 561FT3 service manual 1-25





Diagnostic points



HAZARDOUS VOLTAGE
Risk of electrical shock



Disconnect all
sources of supply
prior to servicing



Component	Wire		
Control panel	Red - Blue		DC0-5V (pulsed voltage) The resistance is infinity but the current flow when the switch is pushed.
	Blue - Blue		
Hi-Limit SW etc.	White - White		Below DC 1V, Below 1Ω
	Blue or Yellow – White (OHS1)		
	Blue or Yellow – White (OHS2)		
	White - White (TF)		
Hi-Limit TH1	Blue (Black) – Blue (Black)		0.64-630.1kΩ (<0.64kΩ:Short, >630.1kΩ:Open)
	Temperature		0.64-558.8kΩ(<0.64kΩ:Short, >558.8kΩ:Open)
	Blue (Black) Blue (Black) (Filter sign)	High	NG: Flashes below 3.90kΩ, LP: Flashes below 3.90kΩ
		Low	NG: Flashes below 8.62kΩ, LP: Flashes below 8.62kΩ
	Blue (Black) Blue (Black) (TH operate)	High	NG: Operates below 2.92kΩ, LP: Operates below 2.92kΩ
		Low	NG: Operates below 5.29kΩ, LP: Operates below 5.29kΩ
Hi-Limit TH2	Black (Black) - Black (Black)		0.64-558.8kΩ (<0.64kΩ:Short, >558.8kΩ:Open)
	Temperature		0°C:213.7kΩ, 20°C:78.2kΩ, 50°C:21.5kΩ, 80°C:7.29kΩ, 100°C:3.90kΩ,135°C:1.52kΩ”
	Black (Black) Black (Black) (TH operate)	High	NG: Operates below 8.62kΩ, LP: Operates below 8.62kΩ
		Low	NG: Operates below 8.62kΩ, LP: Operates below 8.62kΩ
RT TH	Red (Black) - Red (Black)		1.37-580.6kΩ (<1.37kΩ:Short, >580.6kΩ:Open)
	Temperature		0°C:112.8kΩ 20°C:38.6kΩ, 30°C:23.5kΩ, 40°C:14.6kΩ
FR	Yellow - FR terminal		Below 0.1μA (when stopped)
Sparker	Red - Blue		AC187-264V
Combustion fan (in case of short vent)	White-Black		DC13.5-16.5V
	Blue - Black		Below ignition revolution +2Hz
	Ignition revolution	Initial	LP: 56Hz, NG: 65Hz
		Re-attempt	LP: 56Hz, NG: 65Hz
	Normal revolution	High	LP: 116Hz, NG: 114Hz
		Low	LP: 65Hz, NG: 70Hz
Combustion fan (in case of long vent)	White - Black		DC13.5-16.5V
	Blue - Black		Below ignition revolution +2Hz
	Ignition revolution	Initial	LP: 59Hz, NG: 68Hz
		Re-attempt	LP: 59Hz, NG: 68Hz
	Normal revolution	High	LP: 120Hz, NG: 118Hz
		Low	LP: 70Hz, NG: 75Hz
Convection fan	White - Black		DC13.5-16.5V
SV1, 2	Blue - Black		DC10-14V34-42Ω
	White - Black		
POV	Red - White		DC1-14V (Low-High) 65-90Ω
Pressure sensor	White - Black		DC0.25-4.8V
	Red - Black		DC4.75-5.25V


Wiring diagram



HAZARDOUS VOLTAGE
Risk of electrical shock



Disconnect all
sources of supply
prior to servicing




RHFE-309FT3 / RHFE-559FT3 / RHFE-561FT3


MARK	NAME
MS	Main switch
R. TH	Thermistor
TF	Thermal fuse
F	Fuse
ER	Electrode
POV	Modulating solenoid valve
OH, TH1, 2	OH thermistor 1, 2
OHS	OH switch
FM	Convection fan motor
SP	Sparker
SV1, 2	Main SV 1, 2
BL	Combustion fan motor
FR	Flame rod
TB	Terminal block
PS	Pressure sensor

CODE	COLOUR	CODE	COLOUR
bk	black	w	white
bl	blue	y	yellow
lb	light blue	gy	grey
gr/y	green/yellow	or	orange
r	red	br	brown

Block diagram




Time charts (1 of 3)



Time charts (2 of 3)

UNIVERSAL CONTROL TIME CHART	P2 of 3	MIS-FIRE 11 FLASHES	SPARK CATCH MISTAKE 53 FLASHES	
NATURAL DRAFT: NAT GAS or LP GAS				
ON OFF BUTTON				
OPERATION INDICATOR	BLUE RED			
IGNITOR				
SPARK SENSOR				
SOLENOID VALVE SV1, SV2				
MODULATING VALVE	7 6 5 4 3 2 1			
SOLENOID VALVE SV3				
SOLENOID VALVE SV4				
FLAME ROD 1				
CONVECTION FAN				
OVERHEAT THERMISTOR				
FILTER LAMP				
PILOT BURNER COMBUSTION				
MAIN BURNER COMBUSTION				
REMARKS		15"	2"	

Time charts (3 of 3)



Dismantling for service



HAZARDOUS VOLTAGE
Risk of electrical shock



Disconnect all
sources of supply
prior to servicing





To secure metallic panel 8g Pan Head - self taper 	Front/side panel louvre 8g Pan Head - self taper with captive star washer 	Gas connecting tube Pan Head M4 with captive spring washer 
Earthing lead Pan Head M4 with captive star washer 	To secure plastics, exhaust pipe Flat Head 8g - self taper 	To secure air intake tube Flat Head M4 

Removal of front panel

1. Grip sides of skirt and pull forward to remove.
2. Remove five screws to release louvre and front panel.
3. Remove the louvre.
4. Grip bottom left and right corners of the front panel, lift and pull forward to release.



Removal of top panel, control panel, and control panel PCB

1. Remove two screws, one each side of the control panel.
2. Release the three multi-pin connectors from main PCB, releasing the control panel harness from wire clip on main PCB casing.
3. Pull forward of control panel and lift both sides to remove.
4. Unscrew five screws to remove control PCB from control panel.



Removal of convection fan motor

1. Loosen Allen screw securing the fan blade to the fan motor shaft using a 3 mm Allen key from the back of the unit.
2. Remove the securing bracket (two screws).
3. Remove the four screw securing the motor to the casing and remove fan motor cover.





Removal of heat exchanger







The combustion tube gasket must be replaced whenever a burner tube cover plate has been removed.

Take care not to damage o-ring on gas supply tube when removing right hand side of heat exchanger assembly.

1. Remove earth connection on front of heat shield.
2. Release fusible link.
3. Release ten screws securing the heat shield.
4. Disconnect overheat switch and thermistor, two screws.
5. Disconnect flame sensing lead (pull hard). Carefully remove spark sensing lead and high tension lead.
6. Remove top panel (three screws), and right hand side panel (three screws).
7. Remove blanking panel (two screws).
8. Remove gas supply tube securing screw (gas control side) and two air intake tube securing screws.
9. Remove two burner securing screws to remove the gas supply tube.
10. Disengage gas supply tube and manifold.
11. Remove flue spigot (three screws).
12. Remove the heat exchanger securing screws. Grip the heat exchanger and pull forward to remove.







Removal of burner




When reassembling the burner replace gasket to ensure an airtight burner chamber.

1. Remove front heat shield.
2. Remove blanking panel, two screws.
3. Remove spark sensing lead, and high tension lead (pull off gently).
4. Remove two gas supply tube securing screws.
5. Disengage gas supply tube.
6. Remove burner cover screws (four)
7. Gently manoeuvre burner and cover forward and out of the burner chamber by pulling on manifold. Take care not to damage the gasket.




Removal of flame rod

Remove the one screw securing the flame rod, and lift flame rod.



Removal of main PCB

1. Remove securing bracket—two screws.
2. Disconnect all multi-pin connectors and wire harness from clips of PCB casing.
3. Remove earth connection on front of heat shield.
4. Release PCB by removing the three screws. Lift PCB on RHS and gently manoeuvre it out.




Removal of combustion fan



Arrow must be aligned when fan assembly is replaced.

Remove main PCB. Remove combustion fan securing screws (4). Grip fan motor plate and pull forward to remove fan from casing. Remove connector from fan motor.



Removal of main transformer

Disconnect electrical supply.



1. Remove front blanking panel screw on transformer.
2. Release the two multi-pin connectors from the main PCB.
3. Remove securing screw from transformer mounting bracket.
4. Pull forward.



Removal of gas control

Ensure gas supply is turned off at the meter and the appliance is disconnected. Ensure test point screw is fitted to gas controls, if fitting a new control.

1. Remove front panel assembly.
2. Release solenoid connectors, gas supply tube securing screw, and gas supply tube. Take care with the o-ring.
3. Remove the screws surrounding the gas inlet at the back of the heater (4).
4. Pull gas control assembly forward to remove.



Removal of room thermistor

The room temperature thermistor and heat exchanger overheat thermistor are on one harness. After removing the front panel, and rear spacer panels, unclip the thermistor from purse locks behind the appliance.


Remove one earth connection on the front of the heat shield. Release fusible link.

Remove the ten screws securing the heat shield and lift heat shield off. remove overheat thermistor.

Removal of thermal fuse

Turn off gas meter and disconnect appliance from installation.

1. Remove front, and rear spacer panels.
2. Remove earth connection on front of heat shield.
3. Release fusible link.
4. Release the ten screws securing the heat shield.
5. Disconnect wire connector along harness to release completely from appliance.
6. Remove two screws securing the thermal fuse.
7. Release thermal fuse from appliance.





Notes



Notes

Rinnai.co.nz

Tel: 0800 746 624

<http://www.youtube.com/rinnainz>

<http://facebook.com/rinnainz>