

MODEL: RIB23 (SAPPHIRE / NEO)

LOG LOCATION GUIDE



Ensure that the left hand log is sitting on top of the 2 support brackets (NOT directly on Burner)



Ensure left hand log is pushed hard against LH side and Rear Ceramic Panels



Don't place granules directly in front of the Pilot Flame

