

MODEL: (RHFE1253/ EVOLVE)

STONE LOCATION GUIDE



Ensure that the ceramic panels are pushed hard to the side and rear.



Ensure there are NO granules placed directly over the burner ports to the front and back of the pilot burner or on the flame rods.

Ensure that no Wire Wool can come into contact with the Flame Rod



MODEL: (RHFE1253/ EVOLVE)

LOG LOCATION GUIDE



Ensure that the Ceramic Panels are pushed hard to the Side and Rear



Ensure there are NO granules placed directly over the burner ports to the front and back of the pilot burner or on the flame rods.



Ensure that no Wire Wool can come into contact with the Flame Rod

