MODEL: (RHFE951, 952, 950X / EVOLVE)

STONE LOCATION GUIDE





Ensure that the ceramic panels are pushed hard to the side and rear





Place the granules evenly around and in the gaps between the stones. DO NOT place the granules near the flame rods or the pilot (circled area above) as this will cause blockages in the appliance.

LOG LOCATION GUIDE





Ensure that the Ceramic Panels are pushed hard to the Side and Rear





Place the granules evenly around and in the gaps between the logs. DO NOT place the granules near the flame rods or the pilot (circled area above) as this will cause blockages in the appliance.