

MODEL: LINEAR RHFE800F

LOG LOCATION GUIDE



Align the Centre Log with the triangle indicator hole



Make sure that the Wire Wool does not touch the Flame Rod



Make sure that the Wire Wool does not touch the Flame Rod