


Maxim X7SS (2006) BBQ

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.




Ref.	Description	Qty.	Part No.
1	Hood	1	18171
2	Hood trim plate	1	18620
3	Protective pad front/rear	4	18232
4	Temperature gauge	1	17308
5	Hood badge	1	17104
6	Hood handle	1	18172
7	Cooking rack - fixed	1	18182
8a	Grill plate	3	18250
8b	Hotplate	1	18337
9	Flame tamer	3	18183
10	Body panel - left	1	18175
11	Body panel - right	1	18176
12	Body panel - front	1	18152
13	Body panel - rear	1	18177
14	Burner main: - Serial no. up from 6-07-48884 - Serial no. up to/incl. 6-07-48884	5 5	18271 18406
15	Burner support bracket	1	18154
16	Cross lighting bracket: - Serial no. up from 6-07-48884 - Serial no. up to/incl. 6-07-48884	4 4	18272 18016
16c	Injector: - Serial no. up from 6-07-48884 - Serial no. up to/incl. 6-07-48884	5 N/A	18539 N/A
17	Electric wire set	1	18195
18	Electric igniter - 4 port	1	17139
19	Electric igniter - 2 port	1	17294
20	Electric wire set - 5 point	1	18196
21	Electric wire set - 2 point	1	18194
22	Gas valve, manifold & heat shield	1	18248
22a	Heat shield	1	18202
22b	Back burner gas valve	1	18203
22c	Main gas valve	1	18204
22d	Manifold	1	18219
23	Decorative front panel	1	18241
24	Control panel - with print	1	18629
25	Control knob - main/side burners	6	18213
26	Control knob seat	7	18212
27	Grease tray track - left	1	18224
28	Grease tray track - right	1	18225

Ref.	Description	Qty.	Part No.
29	Grease draining tray	1	18199
30	Grease draining tray heat shield	1	18237
31	Grease receptacle	1	18198
32	Body wind shield	1	18239
33	Back burner frame	1	18187
34	Side shelf - left	1	18180
35	Side shelf - right	1	18181
36	Tool holder	1	18228
37	Tool hook	4	18229
38	Trolley bottom shelf	1	18179
40	Castor seat - LF/RR	2	18222
41	Castor seat - RF/LR	2	18223
42	Trolley legs with side panel - left	1	18244
43	Trolley legs with side panel - right	1	18245
46	Trolley rear panel	1	18246
47	Trolley rear panel bracket	1	18207
48	Trolley bracket - front	1	18208
49	Door stop plate	4	18226
50	Door guide plate	1	18227
51	Door - left	1	18217
52	Door magnet	4	18233
53	Door trim plate	2	18242
54	Door spacer	4	18236
55	Door - right	1	18218
56	Door handle	2	18173
57	Door hinge bracket - top left	1	18159
58	Door hinge bracket - top right	1	18209
59	Door hinge bracket - bottom left	1	18210
60	Door hinge bracket - bottom right	1	18211
61	Trolley partition panel - left	1	18243
62	Trolley partition panel bracket - left	1	18206
65	Cylinder pull out tray	1	18169
66	Castor 3" with brake	4	18220
67	Regulator with hose - LPG	1	18215
72	Manual lighting tube	1	18221
A1	Body panel outside - right	1	18178
A2	Side burner grease tray track assy	1	18231

Refer next page for parts **A3-B8** (in red)

Maxim X7SS (2006) BBQ

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
A3	Side burner body assy	1	18189
A4	Side burner body bracket	2	18158
A5	Side burner lid	1	17244
A6	Pot support	1	17246
A7	Side burner electrode	1	18192
A10	Side burner body with brass ring	1	18184
A11	Side burner bracket	1	18188
A12	Side burner wind shield	1	18238
B1	Back burner assy	1	18185
B2	Back burner orifice	1	18235
B3	Back burner extension tube	1	18216
B4	Back burner collector box	1	18197
B6	Back burner electrode	1	18193
B7	Back burner wind shield	1	18240
B8	Back burner control knob	1	18214
-	Hardware pack	1	18234
-	Cover	1	ABBQ2019
-	BBQ burner uprating kit, only available for BBQ's with serial numbers up to 6-07-48884	1	18542
-	#3 Phillips screwdriver	1	18230