

Rinnai | Continuum consolidated spares list

This consolidated parts list is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Description	RNZ Part No.
Bracket Infinity Continuum 250	7697
Bracket Infinity Continuum 330	7698
Bracket power box	7699
Thermostat L6188A201	7648
Pump Wilo RS25/6RG B	7649
Power cord black	6765B
Inline water valve 20 mm	7657
Elbow Crox/M brass 20 mm	7659
Bush brass 25 x 20 mm	7660
Reducing nipple brass 25 x 20 mm	7661
Plug 50 mm	7685
Valve HT575/1000 15 RMC	7687
Bush brass 50 x 20 mm	7688
Water connector 20 x 300 (250/330 L)	7658
Water connector 20 x 450 250 L	7664
Water connector 20 x 600 330 L	7665
Wiring diagram	7647
Label Continuum 250 L internal	7652
Label Continuum 250 L external	7653
Label Continuum 330 L internal	7654
Label Continuum 330 L external	7655
Tek screw	9000
Screw 4 g x ¾ PHPZS	9003
Terminal block	5034
Enclosure Marley EE240 100 x 54	7689
Cable 3-core ord/duty 1.0 black	7693
Gland cable nylon GN16 16 mm	7694