


# Maxim M5S BBQ

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
1	Hood	1	17667
2	Hood hinge set	2	17668
3	Temperature gauge	1	17669
4	Hood panel - left	1	17670
5	Hood panel - right	1	17671
6	Hood hinge support - left	1	17672
7	Hood hinge support - right	1	17673
8	Hood handle	1	17674
9	Hood handle spacer - left	1	17675
10	Hood handle spacer - right	1	17676
11	Protective pad - front	2	17677
12	Protective pad - rear	2	18232
13	Secondary cooking (warming rack)	1	18266
14	Grill plate	3	ABBQ2089
-	Grill plate cast iron (320 x 485 mm) Use as an alternative if there is no stock left of ABBQ2089	-	ABBQ2082
15	Hot plate	1	17584
16	Flame tamer	3	17604
17	Bowl panel - left	1	17678
18	Bowl panel - right	1	17679
19	Bowl panel - front	1	17680
20	Bowl panel - rear	1	17681
21	Bowl wind shield	1	18045
22	Grease tray track - left	1	18070
23	Grease tray track - right	1	18071
24	Main burner	5	18271
25	Burner support bracket	1	18051
26	Gas collector with electrode	4	18272
27	Upper decorative front panel	1	17682
28	Control panel	1	17683
29	Electric igniter - 4 port	1	17658
30	Control knob - main burner	5	17619
31	Control knob seat - main burner	5	18212
32	Manifold/heat shield assembly)	1	17684
32a	Gas valve - main with jet	5	18277
32b	Jet main burner - ULPG	4	18538
32c	Heat shield	1	18056
32d	Manifold	1	18069
33	Regulator with hose	1	17685
34	Grease receptacle	1	18198

Ref.	Description	Qty.	Part No.
35	Grease draining tray	1	18199
36	Grease draining tray heat shield	1	18237
37	Side shelf - left	1	17526
38	Side shelf decoration panel - left	1	17686
39	Side shelf - right	1	17688
40	Side shelf decoration panel - right	1	17687
41	Tool holder	1	18228
42	Tool hook	4	18229
43	Trolley bottom shelf - ULPG	1	17689
44	Trolley legs with side panel - left	1	18283
45	Trolley legs with side panel - right	1	18284
46	Trolley rear panel	1	18285
47	Trolley bracket - front	1	17690
48	Castor seat - left front & right rear	2	18222
49	Castor seat - right front & left rear	2	18223
50	Door hinge bracket - bottom left	1	18288
51	Door hinge bracket - top left	1	18287
52	Door hinge bracket - bottom right	1	18024
53	Door hinge bracket - top right	1	18023
54	Door stop plate	1	17691
55	Door stop magnet	4	18030
56	Door assembly	2	17692
57	Castor wheel 3 " with brake	4	18220
58	Hose holder	1	18601
59	Side burner hose	1	18066
60	Gas valve side burner	1	18039
61	Control knob seat - side burner	1	17693
62	Control knob - side burner	1	17694
63	Side burner body bracket	2	18021
64	Side burner electrode	1	18646
65	Side burner bracket	1	18188
66	Side burner body	1	18645
67	Side burner	1	18184
68	Side burner pot support	1	17246
69	Side burner lid	1	18000
70	Electric wire set	1	18054
-	Rotisserie kit	1	ABBQ1318