


Maxim S5S BBQ

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
1	Hood	1	17695
2	Hood hinge set	2	17727
3	Cotter pin	2	17728
4	Hood trim plate	1	17696
5	Temperature gauge	1	17669
6	Hood panel - left	1	17670
7	Hood panel - right	1	17671
8	Hood hinge support - left	1	17734
9	Hood hinge support - right	1	17736
10	Hood handle	1	17674
11	Hood handle spacer - left	1	17675
12	Hood handles spacer - right	1	17676
13	Protective pad - front	2	17677
14	Protective pad - rear	2	18232
15	Secondary cooking (warming rack)	1	18182
16	Grill plate	3	18250
-	Grill plate cast iron (320 x 485 mm) Use as an alternative if there is no stock left of 18250	-	ABBQ2082
17	Hotplate	1	17584
18	Flame tamer	3	17699
19	Bowl panel - left	1	17737
20	Bowl panel - right	1	17738
21	Bowl panel - front	1	17739
22	Bowl panel - rear	1	17740
23	Bowl wind shield	1	17741
24	Grease tray track - left	1	17742
25	Grease tray track - right	5	17743
26	Main burner	5	18271
27	Burner support bracket	1	18154
28	Gas collector with electrode	4	18272
29	Upper decorative front panel	1	17744
30	Control panel	1	17745
31	Electric igniter - 4 port	1	17658
32	Control knob - main seat burner	5	17619
33	Control knob seat - main burner	5	18212
34	Manifold/heat shield assembly:	1	17684
34a	- gas valve main with jet	1	18277
34b	- jet main burner ULPG	1	18538
34c	- heat shield	1	18056
34d	- manifold	1	18069
35	Regulator with hose ULPG	1	17726
36	Grease receptacle	1	18198
37	Grease draining tray	1	18199

Ref.	Description	Qty.	Part No.
38	Grease draining tray heat shield	1	18237
39	Side shelf - left	1	17717
40	Side shelf decoration panel - left	1	17719
41	Side shelf - right	1	17746
42	Side shelf decoration panel - right	1	17720
43	Tool holder	1	18228
44	Tool hook	4	18229
45	Trolley bottom shelf	1	17747
46	Trolley legs with side panel - left	1	18617
47	Trolley legs with side panel - right	1	18168
48	Trolley rear panel	1	17748
49	Trolley bracket - front	1	17749
50	Castor seat - left front/right rear	2	18222
51	Castor seat - right front/left rear	2	18223
52	Door hinge bracket - bottom left	1	18210
53	Door hinge bracket - top left	1	18159
54	Door hinge bracket - bottom right	1	18211
55	Door hinge bracket - top right	1	18209
56	Door stop plate	1	18227
57	Door stop magnet	4	18226
58	Door assembly	2	17750
59	Partition panel	1	18075
60	Partition panel bracket	1	18206
61	Gas cylinder tray assembly	1	17724
62	Gas cylinder tray handle	1	17725
63	Castor wheel 3" with brake	4	18220
64	Hose holder	1	18601
65	Side burner hose	1	18066
66	Gas valve - side burner	1	18039
67	Control knob seat - side burner	1	17693
68	Control knob - side burner	1	17694
69	Side burner body bracket	2	18158
70	Side burner electrode	1	18646
71	Side burner bracket	1	18155
72	Side burner body	1	17730
73	Side burner	1	18184
74	Side burner pot support	1	17246
75	Side burner lid	1	17731
76	Electric wire set	1	18054
-	Rotisserie	1	ABBQ1318
-	Hardware pack	1	17765