
Rinnai

Timberflame Radius Manual (IB35R) gas fireplace

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Part No.
1	Louvre tube 9.5 - silver (x 6)	R1770-2
	Louvre tube 9.5 - black (x 6)	7029BN
	Louvre tube 9.5 - gold (x 6)	7029
2	Flue spigot	7174-1
3	Glass assembly including seal	4996
4	Glass seal replacement tape kit	R7010
5	Panel front painted - silver powder coat (new silver)	7195SP
	Panel front painted - satin black (viper)	7195V
7	Rinnai badge	5327G
8	Glass retaining bracket bottom - black	7037
	Glass retaining bracket bottom - silver	7056S
9	Dress guard NZ	R1776
10	Glass retaining bracket top - silver	7057S
	Glass retaining bracket top - black	7033
11	Louvre tube 15.8 (x 1)	7099
12	Fan switch (rocker)	7089
13a	Flexitube replacement kit (fires manufactured before 21/02/04)	4988
13	Inlet flex tube	7179
14	Front burner	7040
15	Main burner NG	4970
16	Main burner LPG	4971
17	Pilot burner c/w NG pilot injector	7008
18	Rear burner	6384
19	Log locating sleeve	7240
20	Sparker	6917
21	Aeration sleeve - NG only	7258
22	Fan kit	R1903
23	Fan mounting grommet	7129
24	Fan mounting sleeve	7130


Ref.	Description	Part No.	
25	Front heat exchanger	6620	
26	Rear heat exchanger	7027	
27	Control button	6617G	
28	Control button spring clip	6618	
Paint information			
-	Touch-up paint silver	R1880	
-	Touch-up paint - satin black (viper)	R1881	
Paint code and supplier information			
Silver powder coat: Rahasia silver, SP5182			
Old silver: Rinnai silver, Orica 95496618			
Old matt black: Black metallic, Orica 95483276			

Page 1 of 3

Rinnai

Timberflame Radius Manual (IB35R) gas fireplace

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.





Ref.	Description	Part No.
29	Flue guard	7274
30	Flue spigot guide (left/right)	7241L/7241R
31	Flue guard hinge	7216
	Panel surround RH - satin black (viper)	7192V
	Panel surround RH - silver powder coat	7192SP
33	Door spring	7177
34	Panel surround top - silver	7190S
35	Panel surround LH - silver powder coat (new silver)	7191SP
	Panel surround LH - satin black (viper)	7191V
36	Door LH - silver powder coat (new silver)	7193SP
	Door LH - satin black (viper)	7193V
37	Door RH - satin black (viper)	7194V
	Door RH - silver powder coat (new silver)	7194SP
38	Panel top assembly - silver powder coat (new silver)	7189SP
	Panel top assembly - matt black	7189

Rinnai

Timberflame Radius Manual (IB35R) gas fireplace

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.







Ref.	Description	Part No.
40	Zero clearance plinth - satin black (viper)	R1783-1V
41	Zero clearance heater support	R1783-3
42	Zero clearance side panel	R1783-4
43	Zero clearance base panel	R1783-5
44	Zero clearance top panel	R1783-6
45	Zero clearance rear panel	R1783-7
46	Louvre bracket top IB painted (x 2) Goes at the top of the combustion chamber to hold the top louvres in place at the sides	7217

Gas supply tube spare part information

In 2004 changes were made to the way in which the gas supply tubes were made. For the IB35R this change occurred on the 23/04/2004, serial number 12673 onwards. If ordering any of the below parts, double check the serial number so the correct part can be ordered.

•	Gas supply tube A middle Old pre 23/04/2004 New 23/04/2004 onwards	7161 + 7519* 7784
•	Gas supply tube B front Old pre 23/04/2004 New 23/04/2004 onwards	7162 7785
•	Gas supply tube C rear	

Old pre 23/04/2004 7163 New 23/04/2004 onwards 7786

Description	Part No.	
Spares not shown in exploded diagrams		
Conversion kit (LPG to NG)	R1789	
Conversion kit (NG to LPG)	R1797	
Cord holder	6653	
Electrode	7007	
Fan sensor switch (refer image below)	6635	
Fan switch relocation template	2549	
Flare nut %	5030	
Flue seal foam	7186R	
Gas control assembly	4995	
Gas tube retainer	6643	
Injector Bray 170 LPG - middle	7184	
Injector Bray 440 NG - middle	7181	
Injector Bray 200 NG - front	7183	
Injector 0.80 mm LPG front	5450	
Injector 0.90 mm LPG rear	5436	
Injector 1.30 mm NG - rear	5452	
Log set c/w granules	7044	
Pilot injector LPG 0.30 mm	7009	
Pilot injector NG 0.45 mm	9600	
Power cord	6765B	
Thermocouple clip (2000)	9377	
Thermocouple c/w OHS	7118	
Universal high tension lead (also known as a sparker lead)	R7205	
Wiring diagram	7052	
Wiring harness	7248	
Zero clearance box	AAC1783	
Zero clearance kit	R1783	

^{*} Also need to order 7519 nut and olive