


Rinnai

INFINITY XR16 external (REU-V1620WG)


This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



| Ref.              | Description                    | Qty. | Part No.  |
|-------------------|--------------------------------|------|-----------|
| SI = stocked item |                                |      |           |
| 001               | Front panel assembly           | 1    | 3261 (SI) |
| 010               | Wall bracket                   | 2    | 3387 (SI) |
| 011               | Seal packing                   | 1    | 2898      |
| 012               | Rubber bush C                  | 1    | 2881      |
| 015               | Connection reinforcement panel | 1    | 2864      |
| 130               | Flue outlet                    | 1    | 3263      |
| 131               | Flue outlet packing            | 1    | 3282      |
| 132               | Main body seal packing         | 1    | 3283      |
| 800               | Screw                          | 1    | 2897      |
| 801               | Truss screw                    | 3    | 2939      |

# INFINITY XR16 external (REU-V1620WG)

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.




| Ref.              | Description                          | Qty. | Part No.  |
|-------------------|--------------------------------------|------|-----------|
| SI = stocked item |                                      |      |           |
| 103               | Manifold assembly A LPG              | 1    | 4885 (SI) |
| 103               | Manifold assembly E NG               | 1    | 4886 (SI) |
| 104               | Manifold packing top                 | 1    | 3273      |
| 105               | Manifold packing lower               | 1    | 5788      |
| 106               | Burner case front                    | 1    | 3266      |
| 107               | Packing                              | 1    | 3279      |
| 108               | Damper A                             | 1    | 4889(SI)  |
| 109               | Lean & rich burner assembly          | 14   | 2941      |
| 110               | Burner case rear                     | 1    | 3267      |
| 111               | Combustion chamber front             | 1    | 3262      |
| 112               | Combustion chamber packing top       | 1    | 3280      |
| 113               | Electrode                            | 1    | 3445 (SI) |
| 114               | Flame rod electrode                  | 1    | 4916 (SI) |
| 115               | Electrode packing                    | 1    | 3465 (SI) |
| 116               | Electrode holder                     | 1    | 3468 (SI) |
| 117               | Electrode sleeve                     | 1    | 3475 (SI) |
| 120               | Heat exchanger assembly              | 1    | 4919 (SI) |
| -                 | Heat exchanger high acidity assembly | 1    | 4910 (SI) |
| 150               | Fan motor assembly                   | 1    | 5782 (SI) |
| 151               | Fan casing assembly                  | 1    | 3404 (SI) |
| 703               | Ignitor assembly                     | 1    | 2886 (SI) |
| 704               | HT lead universal                    | 1    | 3651 (SI) |
| 705               | Ignitor fixing plate                 | 1    | 3249      |
| 713               | Heater fixing plate                  | 4    | 2899      |
| 719               | Temperature fuse fixing plate        | 2    | 3659 (SI) |
| 720               | Temperature fuse fixing plate        | 2    | 4899 (SI) |
| 802               | Screw                                | 3    | 2938      |
| 803               | Tapping screw                        | 1    | 2896      |
| 827               | O-ring                               | 1    | 4912 (SI) |
| 828               | O-ring                               | 1    | 3826 (SI) |

Rinnai

INFINITY XR16 external (REU-V1620WG)

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.




| Ref.              | Description                 | Qty. | Part No.   |
|-------------------|-----------------------------|------|------------|
| SI = stocked item |                             |      |            |
| 013               | Quick control connection    | 1    | 2877       |
| 014               | Cable seal packing          | 1    | 2928       |
| 100               | Gas connection              | 1    | 3074 (SI)  |
| 101               | Test point screw c/w o-ring | 1    | 15330 (SI) |
| 102               | Gas control                 | 1    | 5753 (SI)  |
| 121               | Fixing bracket              | 1    | 3331 (SI)  |
| 122               | Fixing bracket              | 1    | 3332 (SI)  |
| 400               | Water inlet                 | 1    | 3210       |
| 401               | Plug band inlet             | 1    | 2927 (SI)  |
| 402               | Incoming water filter       | 1    | 3839 (SI)  |
| 404               | Balancer                    | 1    | 3487 (SI)  |
| 404a              | Water turbine               | 1    | 2850       |
| 405               | Water servo & sensor LPG    | 1    | 2944 (SI)  |
| 405               | Water servo & sensor NG     | 1    | 2945 (SI)  |
| 406               | Water servo cover           | 1    | 2871       |
| 408               | Hot water outlet            | 1    | 3214       |
| 409               | Plug band hot water         | 1    | 2926       |
| 410               | Pressure relief valve       | 1    | 3491 (SI)  |
| 700               | PCB main assembly           | 1    | 3238 (SI)  |
| 701               | EC cover 2-Z                | 1    | 2872       |
| 702               | PCB cover                   | 1    | 2866       |
| 706               | Surge protector             | 1    | 4930 (SI)  |
| 707               | Sub circuit board cover     | 1    | 2873       |
| 708               | Fixing plate                | 1    | 2925       |
| 804               | Thermistor stop screw       | 1    | 3241       |
| 820               | O-ring                      | 2    | 2239 (SI)  |
| 821               | Gas inlet o-ring            | 1    | 3837 (SI)  |
| 822               | Packing                     | 2    | 3773 (SI)  |
| 825               | O-ring                      | 1    | 3832 (SI)  |
| 829               | O-ring                      | 1    | 1244 (SI)  |
| 830               | O-ring                      | 1    | 3627 (SI)  |

Rinnai

INFINITY XR16 external (REU-V1620WG)

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



| Ref.              | Description                 | Qty. | Part No.  |
|-------------------|-----------------------------|------|-----------|
| SI = stocked item |                             |      |           |
| 709               | Power cord                  | 1    | 3526 (SI) |
| 710               | Fuse harness LPG            | 1    | 2855 (SI) |
| 710               | Fuse harness NG             | 1    | 2854 (SI) |
| 711               | Valve water heater assembly | 1    | 4900 (SI) |
| 712               | Frost sensing switch        | 1    | 3358 (SI) |
| 715               | Electric power harness      | 1    | 2888 (SI) |
| 716               | Magnet valve harness        | 1    | 2889 (SI) |
| 717               | Sensor harness              | 1    | 3248 (SI) |
| 718               | Thermal fuse harness        | 1    | 4896 (SI) |
| 721               | MR sensor                   | 1    | 3771 (SI) |
| 722               | Thermistor                  | 1    | 2884 (SI) |
| 725               | Remote controller harness   | 1    | 2891      |