


Rinnai | Energysaver 557FTR heater

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.




Ref.	Description	Qty.	Part No.
001	Rear panel assembly	1	4000
002	Top panel bracket	1	Not available
003	Filter bracket - side	1	4001
004	Filter bracket - bottom	1	4002
005	Back panel heat shield	1	Not available
007	Control panel - white	1	4380
008	Control cover - tinted	1	4004
-	Control panel lid	1	4084
009	Front panel - white	1	4021
010	Louvre	1	4087
011	Louvre assembly	1	4088
012	Skirt - white	1	4101
013	Side panel LH - white	1	4102
014	Side panel RH - white	1	4110
015	Humidifier tray	1	4116
016	Air filter - white	1	4117
017	Front foot	2	3403
018	Rear foot	2	3405
019	PCB bracket panel	1	Not available
020	Strike	2	3038
021	Latch	2	3028
022	Cord brush	1	6653
023	Electrical cord holder	1	1952
024	Cable clip	2	6657
025	Thermistor holder	1	4252
026	Wire clip	4	2156
027	Bush	1	Not available
029	Top spacer - beige	1	4121
029	Top spacer - white	1	4121W
030	Back spacer RH - white	1	4210
031	Back spacer LH - white	1	4228
032	Wall clip	2	6684
033	Back spacer bracket	2	3542
034	Wiring diagram / pressure setting label	1	Not available
708	Room temperature thermistor	1	4386
712	Electrical cord	1	3115

Rinnai


Energysaver 557FTR heater

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
026	Wire clip	4	2156
400	Convection flue casing	1	Not available
401	Convection fan drum	1	4376
402	Motor securing bracket	1	Not available
403	Convection fan motor	1	4377
404	Convection fan capacitor	1	4378
405	Heat shield	1	Not available
406	TF fixing bracket B	1	Not available
407	OHS fixing bracket	1	Not available
408	PCB mounting panel	1	Not available
409	PCB bracket	1	Not available
410	Transformer fixing bracket	1	Not available
700	PCB	1	4379
702	Transformer	1	4381
703	Sparker	1	2958
704	High tension cord	1	4383
710	TF harness B	1	4388

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.




Ref.	Description	Qty.	Part No.
100	Heat exchanger	1	4229
101	OHS fixing bracket	1	Not available
102	Flame rod bracket	1	Not available
103	Flame rod packing B	1	4230
104	Flame rod	1	4299
105	Comb. chamber fixing bracket	1	Not available
106	Heat exchanger fixing bracket	1	Not available
107	Seal panel assembly B	2	Not available
108	Flange	2	Not available
109	Burner box	1	4370
110	Burner NG/LPG	4	3091
111	Burner clip	1	Not available
112	Burner box packing	1	4231
113	Primary air damper	1	4390
114	Secondary air damper NG	1	4238
114	Secondary air damper LPG	1	4267
115	Burner box fixing bracket packing	1	4268
117	Electrode kit (incl. gasket)	1	R1346
119	Injector manifold	1	Not available
120	Main injector NG 1.30	4	2394
120	Main injector LPG 0.85	4	3093
121	Manifold packing	1	3094
122	Sealing panel	1	Not available
123	Burner box cover	1	Not available
124	Heat exchanger packing	1	4306
125	Gas valve	1	4335
126	Pressure point test screw	3	9994
127	Pressure point o-ring	3	9995
128	Gas supply tube	1	4356
129	Gas supply tube o-ring	2	4357

Ref.	Description	Qty.	Part No.
130	Pressure test point	1	4204
131	O-ring	1	1967
132	Packing	1	4358
133	Gas filter	1	4359
134	Gas inlet	1	4360
135	Gas inlet elbow	1	4361
136	Modulating solenoid (part of gas valve)	1	use 4335
704	High tension cord	1	4383
705	Electrode sleeve	1	7564
706	OHS - 90°	1	4384
708	Room temp. thermistor	1	3114
717	Cord packing B	1	Not available

Rinnai | Energysaver 557FTR heater


This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
137	Combustion fan assembly	1	4363
138	Combustion fan casing	1	Not available
139	Anti-vibration rubber	6	4364
140	Motor securing screw	3	Not available
141	Combustion chamber connection tube	1	4365
142	Combustion chamber packing	1	Not available
143	Combustion chamber elbow	1	4366
144	Combustion chamber elbow clip	1	3103
145	Air intake inlet C	1	4367
146	Air intake packing	1	4053
147	Air intake hose	1	4041
148	Air intake elbow	1	4040
149	Flue exhaust elbow	1	4997
150	Flue exhaust o-ring E	1	4368
151	Flue exhaust o-ring D	1	4369
152	Insulation clip	1	4171
153	Exhaust slide tube cover	1	4176
154	Flue exhaust slide tube	1	4372
155	Air intake securing clamp	2	4373
190	Flue AA (75-115 mm)	1	R1350
190	Flue A (115-240 mm)	1	R1351
190	Flue B (240-400 mm)	1	R1352
190	Flue C (400-600 mm)	1	R1353
190	Flue D (600-800 mm)	1	R1353D
190	Flue E (800-1000 mm)	1	R1353E
191	Flue lock stopper	1	3454
192	Flue locking clamp	1	3455

Energysaver 557FTR heater

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
104	Flame rod	1	4299
403	Convection fan motor	1	4377
404	Convection fan capacitor	1	4378
700	PCB	1	4379
701	Control panel PCB harness	1	Not available
702	Transformer	1	4381
703	Sparker	1	2958
704	High tension cord	1	4383
705	Electrode sleeve	1	7564
706	OHS - 90o	1	4384
707	OHS - 130o	1	4385
708	Room temperature thermistor	1	4386
709	Main harness	1	4387
710	TF harness B	1	4388
711	SV harness	1	4389
715	Flame rod lead	1	3467
716	Combustion motor harness A	1	4399
717	Cord packing B	1	Not available

Ref.	Description	Qty.	Part No.
Not shown in exploded diagram			
-	Remote control	1	13100
-	Surge arrestor	1	3212
-	Harness surge arrestor	1	3213
-	Installation kit	1	3112
Flueing related - not shown in exploded diagram			
-	Spiral spacer	4	9833
-	Plastic condensate tube	1	9835
-	Fixing strap	1	9830
-	O-ring for ESPIPE900 & ESDFK	1	4350
-	Spacer for ESPIPE900 & ES-DFK	1	4351
-	Transition box manifold assy (thru-wall flue only)	1	1004
-	Transition box manifold assy (in-wall flue only)	1	1003
-	Header plate, top flue support (in-wall flue only)	1	9831
-	Vertical flue cowl Voumard (in-wall and thru-wall flues only)	1	3232
-	Appliance flue joiner clip (in wall flue only)	1	9834