


Evolve 951 gas fireplace

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.




Ref.	Description	Qty.	Part No.
1	Panel base assy.	1	12705
2	Comb. chamber support LH	1	12706
3	Fascia install bracket	2	12437
4	Comb. chamber support RH	1	12402
5	Air inlet assy.	1	12521
6	Air inlet box front	1	10234
7	Packing for air inlet box	1	10271
8	Protector plastic edge	4	1880
9	Transformer	1	10258
10	Panel heat shield LH	1	12707
12	Comb. chamber assy painted	1	12708F
13	Panel heat shield RH	1	12405
14	Bracket flame rod	1	12621
15	Flame rod	3	12620
16	Flame rod bracket	3	3068
17	Injector block A + C	2	7953
18	Packing injector block	2	10462
19	Panel burner support LH	2	12418
20	Panel burner surround center black	1	12616F
21	Panel burner surround rear black	1	12417F
22	Air diverter	1	12421
23	Panel burner surround front black	1	12415F
24	Heat shield bracket black	1	12423F
25	Heat shield top black	1	12422F
26	PCB box base assy.	1	12489
27	PCB main	1	12539
28	PCB spacer	5	10428
29	PCB display	1	10253
30	Protector plastic edge	3	10471
31	Interface board	1	12494
32	PCB box lid	1	12490
33	Relief spring cover black	1	12414F
34	Ceramic panel groove LH	1	12425
35	Ceramic panel groove rear	1	12426
36	Ceramic panel groove RH	1	12427
37	Glass frame assy.	1	12717
38	Glass frame magnet bracket	2	12624
39	Magnet FS	2	7136
40	Dress guard kit	1	R2778
41	O-ring M10B-4-49	1	4850

Ref.	Description	Qty.	Part No.
42	Flextube 3/8x8 CW 5/8-18 nuts	1	7835
43	Adaptor 1/2 BSP 3/4 SAE flare	1	11944
44	Nut 1/2 compression	1	5064
45	Brass plug 3/4 " SAE flare	1	11948
46	Burner rear assy. black	1	12626F
47	Burner front assy. black	1	12710F
48	Aeration sleeve 19.5 mm front/rear NG	2	12499
50	Grommet 22-PPG32	1	11937
51	Insulating bush	3	10657
52	PCB case receiver	1	10394
53	PCB receiver	1	10393
54	Receiver bracket	1	12486
55	Condensate tray top	1	12484
56	Wire bracket	1	12488
57	Condensate pipe	1	12485
58	Power cord clamp	2	9552
59	Cable clip	6	6698
60	Thermistor holder	1	7540
61	Injector 1.90 rear NG	1	11205
62	Injector 2.10 front NG	1	12508
63	Log set	1	R2781
64	Stone set	1	R2780
65	Wheel kit	2	10751
66	Explosion relief bottom assy.	2	11663
67	Explosion relief top assy.	2	11662
-	Granule pack	1*	2544
-	Foot kit	3	10777

* When a new unit is ordered for the first time two granule packs are supplied with the engine
--


This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
68	Heat exchanger front painted	1	12525
69	Heat exchanger rear	1	10351
70	Comb. chamber HEX bracket	2	12419
71	Bracket sound absorber plate	2	10399
72	HEX sound absorber	2	10477
73	Panel heat shield rear	1	12404
74	Panel top	1	12409
75	Panel comb. fan side cover	1	12412
76	Panel comb. fan cover	1	12413
77	Panel side LH	1	12674
78	Convection fan mount bracket	1	12433
79	Convection fan mount support LH	1	12434
80	Convection fan assy	1	12536
81	Convection fan spacer bracket	1	12436
82	Convection fan mount support RH	1	12435
83	Combustion fan assembly	1	10793
84	Bracket comb. fan inlet clamp	1	10508
85	Tube fan inlet combustion	1	10526
86	Screw 2 truss 4x8 tap zinc	2	9151
87	Packing combustion fan	1	10278
88	Bracket fan combustion	3	10280
89	Combustion fan rubber mount	3	10269
90	Bracket exhaust	1	12420
91	Air inlet hose	1	10349
92	Air inlet elbow B 50x50	2	4328
93	Flue pipe set	1	10313
94	Clamp flue 50 mm	1	4823
95	Exhaust air side	1	4326
96	Flue pipe condensate	1	10446
97	Panel side RH	1	12675
98	Panel top edge	1	12714
99	Cable clip	3	10309
100	Air outlet elbow Ø50	1	10334
101	Heat exchanger clamp	2	12468
102	Inlet adaptor clamp	1	12467
103	HEX inlet adaptor	1	12464
104	Pipe bend heat exchanger	1	12553
105	Bracket A back anti-vibrate	1	12213
106	Bracket B back anti-vibrate	1	12214

Description	Qty.	Part No.
NOT DRAWN		
Power cord uni control black	1	13042
HT lead	1	13032
Tube silicone black	2	10528
Cable cat5 x 1.4 m	1	11925
Wire harness condensate	1	12432
Harness main	1	12477
Harness flame rod	1	12448
Harness combustion fan (OH2)	1	12655
Harness power cord fused	1	12491
Harness 12 way control panel	1	12492
Harness 9 way control panel	1	12496
Harness room temperature thermistor (OH1)	1	13034
Harness OHS thermal fuse	1	10283
Harness receiver	1	12656

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.




Ref.	Description	Qty.	Part No.
1	Gas control assy.	1	12524
2	Olive 6 mm	1	7519
3	Injector pilot NG 75	1	7796
3	Injector pilot LPG 40	1	7905
4	Pilot body top convertible	1	7870
5	Electrode	1	7875
6	Electrode nut ETR	1	7900
7	Spacer electrode pilot	1	7902
8	Electrode double	1	10265
9	Grommet silicone Ø4 hole	2	10293
10	Grommet silicone 2 Ø 1.8 hole	4	10294
11	Gasket injector block	1	11554
12	Pilot base	1	12711
13	Bracket pilot	1	12460
14	Pilot convertible hood 4-flame	1	12463
15	Bracket electrode clamp	1	12461
16	Gas tube pilot B	1	12712
17	Sparker unit	1	2958
18	Gas supply tube rear	1	12456
19	Gas supply tube front	1	12457
20	Gas tube pilot A	1	12458
21	Regulator assy. NG	1	12522
21	Regulator assy. LPG	1	12523
-	Electrode sheath silicone PK2	1	12931

Rinnai

Evolve 951 gas fireplace

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
128	Frame outer galaxy incl. 130, 131, 132	1	12716GL
129	Fascia galaxy spare	1	12528
129	Fascia stainless steel spare	1	12529
130	Main control switch	1	12999
131	Button	1	10250
132	Switch label	1	12718
133	Remote control	1	12201
134	Remote control bracket	1	10396