
Rinnai | EL 1500 Holographic Electric Fire spares

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.







Ref.	Description	Part No.
1	Left LCD driver EL1500	17957
2	Heater unit	17935
3	LCD panel EL1000/1500	17956
4	Down light EL1500	17943
5	Speaker EL1000/1500	17968
6	Right LCD driver EL1500	17964
7	15 A power cord EL1500	17942
8	Hard wire inlet board EL1500	17953
9	Manual control panel EL1000/1500	17961
10	Side panel EL1000/1500	17966
12	Side trim	-
13	Log LED PCB EL1000/1500	17958
14	Fuel bed LED board B EL1500	17948
15	Fuel bed LED board A EL1000/1500	17947
16	Spindle motor EL1000/1500	17969
17	Fuel bed effect spindle EL1500	17946
18	Main PCB EL1500	17960
19	Side glass EL1000/1500	17965
20	Flame screen	17936
21	Front glass	17937
22	Fuel bed up lights EL1000/1500	17952
23	Fuel bed panel EL1500	17951
24	Power unit EL1500	17963
25	Interface board EL1500	17954
26	Remote holographic	17938

FUEL BED SPARES	
Description	**Part No.**
AI-2 log	17919
AI-1 log with connector	17920
AI-3 log with connector	17921
AI-4 log with connector	17922
AI-7 log	17908
AI-8 log	17909
AI-10 log	17923
AI-5 log with connector	17924
AI-6 log with connector	17925
AI-9 log with connector	17926
P-10 log	17928
AD-8 log	17929
AA-16 log	17930
X-14 log	17931
AI-11 log	17932
AI-12 log	
AI-13 log	17933
P-13 log	17934
P-15 log	
G-2 log	
G-3 log	17939

17964: LCD driver right EL1500

