




INFINITY Solar 24 Gas Boost (REU-V2422WS)


This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
	SI = stocked item		
001	Front panel assembly	1	2943 (SI)
002	Front panel packing	3	2940
010	Wall bracket	2	3387 (SI)
011	Seal packing	1	2898
012	Rubber bush C CR	1	2881
015	Connection reinforcement panel	1	2864
130	Exhaust opening	1	2865
131	Flue outlet packing	1	2933
132	Front panel seal packing	1	2934
800	Screw	1	2897
801	Truss screw	3	2939

INFINITY Solar 24 Gas Boost (REU-V2422WS)

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.




Ref.	Description	Qty.	Part No.
	SI = stocked item		
013	Quick control connection	1	2877
014	Cable seal packing	1	2928
100	Gas connection	1	3074
101	Test point screw c/w o-ring	1	15330 (SI)
102	Gas control	1	5753 (SI)
121	Bracket	1	3331
122	Bracket fixing	1	3332
400	Inlet water connection	1	2894
401	Plug band inlet	1	2927
402	Incoming water filter	1	3839 (SI)
404	Balancer	1	3487
405	Water servo & sensor LPG	1	2944
407	Water servo & sensor NG	1	2945 (SI)
406	Water flow servo cover	1	2871 (SI)
408	Hot water connection	1	3420
409	Plug band hot water	1	2926
410	Pressure relief valve	1	3491
700	PCB main assy.	1	3238 (SI)
701	EC cover 2-Z	1	2872
702	PCB cover	1	2866
706	Surge protector	1	4930 (SI)
707	Sub circuit board cover	1	2873
708	Fixing plate	1	2925
804	Thermistor stop screw	1	3241
820	O-ring	2	2239 (SI)
821	Gas inlet o-ring	1	3837
822	Packing	2	3773
825	O-ring	1	3832
826	O-ring	1	1031
829	O-ring	1	1244
830	O-ring	1	3627



INFINITY Solar 24 Gas Boost (REU-V2422WS)

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
	SI = stocked item		
103	Manifold assembly LPG	1	2875 (SI)
103	Manifold assembly NG	1	2876 (SI)
104	Manifold packing top	1	2929
105	Manifold packing lower	1	2930
106	Burner case front	1	2867
107	Packing	1	2931
108	Damper	1	2879 (SI)
109	Lean & rich burner assembly	22	2941
110	Burner case rear	1	2874
111	Combustion chamber front	1	2862
112	Combustion chamber packing top	1	2932
113	Electrode	1	3445 (SI)
114	Front electrode	1	4916 (SI)
115	Electrode packing	1	3465 (SI)
116	Electrode holder	1	3468 (SI)
117	Electrode sleeve	1	3475 (SI)
120	Heat exchanger assembly	1	2946 (SI)
150	Fan motor assembly	1	2883 (SI)
151	Fan casing	1	2863 (SI)
703	Ignitor assembly	1	2886 (SI)
704	HT lead universal	1	3651 (SI)
705	Ignitor fixing plate	1	2900
713	Heater fixing plate	4	2899
719	Temperature fuse fixing plate	2	3659
720	Temperature fuse fixing plate	2	4899
802	Screw	3	2938
803	Tapping screw	1	2896
827	O-ring	1	4912
828	O-ring	1	3826



INFINITY Solar 24 Gas Boost (REU-V2422WS)

This diagram is provided to assist you to identify parts if replacement is necessary. Contact your place of purchase or the manufacturer to enquire about parts, availability and/or service.



Ref.	Description	Qty.	Part No.
	SI = stocked item		
709	Power cord	1	3526
710	Fuse harness-2 LPG	1	2855 (SI)
710	Fuse harness NG	1	2854 (SI)
711	Valve water heater assembly	1	4900
712	Frost sense switch	1	3358
715	Electric power harness	1	2888
716	Magnet valve harness	1	2889
717	Sensor harness solar	1	3239
718	Thermal fuse assembly	1	2887 (SI)
721	MR sensor	1	3771
722	Thermistor	1	2884 (SI)
725	Remote controller harness	1	2891

